




Arcom Communications  
24035 NE Butteville Rd  
Aurora, Oregon 97002  
(503) 678-6182  
arcom@ah6le.net

<http://www.arcomcontrollers.com/>



# ***RC210 Repeater Controller Assembly Manual***

## ***Hardware Version 3.0a***

---

Reproduction or translation of any part of this manual beyond that permitted by sections 107 or 108 of the 1976 United States Copyright Act (or its legal successor) without the express written permission of Arcom Communications is unlawful as noted below. Requests for permission to copy or for further information should be addressed to Arcom Communications. Except as noted above, permission is hereby granted for any non-profit group or individual to reproduce any portion of this document provided that: the reproduction is not sold for profit; the intent of reproduction is to further disseminate information on the RC210 Repeater Controller kit; the reproduction is not used for advertising or otherwise promoting any specific commercial product other than the RC210; and full credit is given to Arcom Communications as the original source of information.

The information contained in the manual has been carefully checked for accuracy and is believed to be entirely reliable. However, no responsibility is assumed for inaccuracies. Arcom Communications reserves the right to make changes in the RC210 Repeater Controller kit to improve reliability, function or design without obligation to purchasers of previous equipment. Arcom Communications does not assume any liability arising out of the application or use of any product or circuit described herein; neither does it convey license under its patent rights or the rights of others.

**This page intentionally left  
blank**

# Parts List

Check off the part in the space provided as you locate and verify against this list.

## Resistors, 1/4 watt

- 16 10k ohm (brown-black-orange-gold)
- 4 22k ohm (red-red-orange-gold)
- 3 47k ohm (yellow-violet-orange-gold)
- 9 100k ohm (brown-black-yellow-gold)
- 3 470k ohm (yellow-violet-yellow-gold)
- 3 110k ohm (brown-brown-yellow-gold)
- 3 33k ohm (orange-orange-orange-gold)
- 16 470 ohm (yellow-violet-brown-gold)
- 2 47ohm (yellow-violet-black-gold)

## Resistor Network

- 1 470 ohm network (10 pin SIP)

## Potentiometers

- 6 10k ohm (C103)
- 3 500k ohm (C504)

## Capacitors

Capacitors may be marked in various ways. The typical markings are given but may vary.

- 23 .1 uf (104)
- 2 33pf (33)
- 2 22pf (22)
- 3 .0068uf (682)

## Electrolytic Capacitors

- 4 1 uf
- 7 2.2 uf
- 4 22 uf
- 1 47 uf
- 2 10 uf

## Diodes

- 4 1N4001 Rectifier (might be 1N4002 or 1N4004)
- 22 1N4148 Silicon Diode
- 4 Red LED
- 4 Green LED
- 4 Yellow LED

## Transistors

- 6 2N3904 NPN

# Integrated Circuits

Do not handle the IC's unnecessarily. Carefully remove the IC tubes from the anti-static bag and check each one against the parts. Then return the tubes with the ICs to the bag.

- 1 ATmega128 (mounted on PCB) (64 pin TQFP)
- 1 ISD4003-04MP VoiceCorder (28 pin DIP)
- 2 ULN2003A (16 pin DIP)
- 1 MT8806 Crosspoint Switch (24 pin DIP)
- 3 MT8870 DTMF Decoder (18 pin DIP)
- 1 ST232 Level Translator (16 pin DIP)
- 2 TL064 Operational Amp (14 pin DIP)
- 2 74HC595 Shift Register (16 pin DIP)

## Sockets

- 3 18-pin DIP Socket
- 1 24-pin DIP Socket
- 1 28-pin DIP Socket
- 2 14-pin DIP Socket
- 5 16-pin DIP Socket

## Voltage Regulators

- 1 5.0 volt (LM340T5 TO-220 case)
- 1 3.3 volt (78L33 TO-92 case)

## Connectors

- 3 9-pin female right-angle PC mount
- 1 25-pin female right-angle PC mount
- 3 RJ45 modular jack
- 1 4 pin power female PCB power
- 1 4 pin power male plug
- 2 36 - pin single row header PC mount
- 1 10 pin dual row header PC mount

## Misc.

- 1 Heatsink
- 1 4-39 screw and nut assembly
- 1 3.579 Mhz crystal (3.57ECSV)
- 1 16 Mhz crystal (160ECSV)
- 1 32768 Khz crystal (small cylindrical)
- 1 10 uh choke (silver-black-black-red-silver)
- 1 Self-resetting Fuse (X030)
- 13 Push-on jumpers
- 1 PC Board (revision 3.0a)
- 1 Assembly Manual
- 1 User Manual

# Construction

You are now ready to begin construction of the RC210. Use a temperature controlled, fine-tipped soldering iron and good quality 60/40 rosin-core solder for construction. Follow standard construction practices when building the unit.

You will also need small flush or semi-flush cutting pliers and small-tipped needle nosed pliers. A magnifying glass may prove useful for identifying the values of small parts.

Keep the tip of the soldering iron bright and clean, wiping it frequently on a wet sponge or rag. Make solder joints carefully, but swiftly. Prolonged heat on a PC board pad can be disastrous and ruining this PC board can be expensive! Two or three seconds should be enough time to apply heat to any joint. Follow the order of construction, as they have been developed to make installation of parts as easy as possible.

The microprocessor (ATMega128) has already been soldered on the board. Great care should be taken when assembling the RC210 to ensure there are no static discharge issues. The use of a grounding wrist strap and grounded tip soldering iron is highly recommended. **(Note: DAMAGE DUE TO STATIC DISCHARGE IS NOT COVERED UNDER WARRANTY)**

## IC Sockets

Note: If any sockets are bent, carefully straighten them with a pair of needle-nose pliers. When installing IC sockets, double check to ensure that the socket is seated properly against the board with the notch, beveled corner or "1" towards the silkscreened reference (U1, IC2, etc). Be sure all IC socket pins are showing on the solder side of the board. While making certain the IC socket is tight against the PC board tack-solder two diagonally opposite corners (such as pins 1 and 14 on a 14 pin socket). Then solder the remaining pins of that socket before proceeding to the next one. If you find a socket is difficult to install, remove it and check for bent pins.

Install the following IC sockets.

- |                   |        |
|-------------------|--------|
| ( ) U6            | 24-pin |
| ( ) U1, U2, U3    | 18-pin |
| ( ) U4, U5        | 14-pin |
| ( ) U7            | 28-pin |
| ( ) IC2, IC3, IC4 | 16-pin |
| ( ) IC5, IC6      | 16-pin |

Now check all your work. All leads should be soldered with no solder bridges or cold solder joints.

## Resistors

Resistors lie flat on the PC board and have a lead spacing of 0.5". You may wish to use a lead former to preform the resistor leads for the neatest appearance.

Install the following resistors 10K (brown-black-orange-gold) resistors:

- ( ) R26, R27, R31
- ( ) R32, R38, R44
- ( ) R45, R51, R54
- ( ) R59, R60, R61
- ( ) R62, R63, R65, R71

Install the following 47K (yellow-violet-orange-gold) resistors:

- ( ) R50, R52, R53

Install the following 22K (red-red-orange-gold) resistors:

- ( ) R34, R55, R67, R66

In the following 47ohm resistors (yellow-violet-black-gold)

- ( ) R29, R43

**( ) Using a clipped off lead, install a wire jumper at R49**

Install the following 470K (yellow-violet-yellow-gold) resistors:

- ( ) R10, R11, R12

Install the following 110K (brown-brown-yellow-gold)

- ( ) R28, R30, R36

Install the following 33K (orange-orange-orange-gold) resistors:

- ( ) R35, R40, R58

Install the following 100K (brown-black-yellow-gold) resistors:

- ( ) R1, R2, R3, R4, R5, R9, R46, R47, R48

Install the following 470 ohm, (yellow-violet-brown-gold) resistors:

- ( ) R6, R7, R8, R15, R16, R17, R18, R19
- ( ) R20, R21, R22, R23, R37, R57, R69, R70

(Resistors R13 and R14 are not included. See Hardware Manual for details)

## Potentiometers

Carefully bend the three leads of each trim pot over 90 degrees, so the leads face the back of the trim pot body. Then insert the leads through the holes in the PC board, with the body closest to the edge of the board, it is flush against the board. Then solder the connections. **(note: the pots should lay down against the board, with the adjustment slot facing up)**

### 10K ohm (C103)

- Port1 Disc, Port2 Disc, Port3 Disc
- Record, Play, Tone

### 500K ohm (C504)

- P1 Tx, P2 Tx, P3 Tx

## Capacitors

The following capacitors are .1uf (104) and should be mounted as close to the board as possible without stressing the leads.

- C1, C3, C5, C6, C9, C14, C15, C16, C17
- C19, C20, C22, C27, C31, C32, C35, C36
- C37, C38, C39, C45, C46, C47

Install the .0068 uf (682) capacitors

- C24, C25, C30

Install the following capacitors:

- C18, C21                    22pf (220)
- C7, C8                        33pf (330) (may be 30pf, marked 30)

## Electrolytic Capacitors

These capacitors are polarized, so care should be taken to orient them properly. Note that at the installation positions for these capacitors, the PC board is marked with a plus (+). Note that the capacitors have the minus (-) lead marked. Install accordingly.

The following are all 2.2uf.

- C23, C26, C29, C34, C41, C44, C48

Install the remaining electrolytic capacitors:

- C11, C12, C13, C60                    1uf
- C10                                        47uf
- C28, C33, C40, C42                    22uf
- C4, C43                                    10uf

## Diodes

Diodes are polarized devices, with the cathode end being banded. Observe polarity when installing the following diodes.

- D1, D2, D3, D5                        1N4001 (may be 1N4004)

Install the following 22 ea. 1N4148 diodes:

- D10, D11, D12, D13, D14, D15, D16, D17, D20, D21, D22  
D23, D24, D25, D26, D27, D33, D34, D35, D36,  
D37, D38

## LEDs

Install the LEDs 1/2" above the board to allow them to be bent over later. Note that one side is flat; this is the cathode. Be sure the flat side of the LED lines up with the flat side on the PC board.

- P1Key, P2Key, P3Key                    Red LED
- P1Cos, P2Cos, P3Cos                    Green LED
- P1Ctcss, P2Ctcss, P3Ctcss            Yellow LED
- P1Dtmf                                    Red Led
- P2Dtmf                                    Green LED
- P3Dtmf                                    Yellow LED

## Transistors

All transistors should be installed with the body not more than 1/4" above the PC board. Match the body of the transistor with the outline on the board and carefully bend the leads to match the hole pattern on the PC board. All transistors are 2N3904

- Q1 - Q6

## Connectors

Carefully install J4 taking care that no pins are bent over as you insert them. Holding J4 flush against the PC board, solder two opposite pins in order to hold it in place. Then solder the remaining pins, taking care to avoid solder bridges

Solder the two larger holes (one on each end) to the pads on the PC board. Use lots of solder to make a mechanically secure connection.

- J4            25-pin female right-angle PC mount

Your RC210 kit comes with 2 types of connectors for J2, J3 and J4 - either DB9 or RJ45 modular jacks. You must now decide which you prefer to use.

- J1            RJ45 or DB9 female right angle PC mount
- J2            RJ45 or DB9 female right angle PC mount
- J3            RJ45 or DB9 female right angle PC mount

Install the Phoenix PC mount 4 pin jack at the location on the PC board marked "Power". It should be installed so it fits inside the outline marked on the PC board.

- Power 4 pin (green)

## Voltage Regulators

IC1 is installed laying down on the PC board with the heatsink between it and the PC board . Carefully bend IC1's leads 90 degrees and insert into the appropriate holes in the board. Slide the heatsink in place and use the supplied 4/40 screw and nut to secure the assembly through the hole in the board.

- IC1 78M05 (LM340T5)

IC7 looks like a transistor. It should be installed just like the transistors.

- IC7 78L033 (CZ-3.3)

## Inductor

L1 looks like a 1 watt resistor. Bend one lead over and install it vertically on the board.

- 1 L1 (silver-black-black-red-silver)

## Crystals

Install the following 2 crystals with the body 1/8 inch above the surface of the PC board (Caution: Make sure you space the crystal as stated, to avoid shorting traces on the PC board).

- Y1 3.579 Mhz crystal (3.57ECSV)
- Y2 16.00 Mhz crystal (160ECSV)

Crystal X1 looks differently from the other 2 crystals - it is a small, cylindrical type with close-spaced leads. X1 should be mounted 1/4 above the PC board, then bent over so it lays flat against the board, away from the Mega128.

- X1 32768 Khz crystal

## Fuse

The RC210 uses a special, self-resetting fuse. It looks like a yellow ceramic capacitor and is marked "X030"

- F1 Fuse

## Resistor Network

The resistor network is a 10 pin single in-line package, colored black. There is a white dot on one end, which indicates pin 1. Line pin 1 up with "1" marking silkscreened on the PC board at RN1.

- RN1 470 ohm resistor network

## Jumper Headers

Locate the 2 - 32 pin jumper header connectors. Carefully cut them between pins (in the notches in the plastic) to create the following:

- 1 10 pin
- 7 3 pin
- 3 5 pin
- 1 6 pin
- 1 8 pin
- 4 2 pin

Install the following pin headers you just created:

- JP1, JP2, JP3 3 pin
- JP4, JP5, JP6 3 pin
- JP7, JP8, JP9, JP13 2 pin
- JP10, JP11, JP12 5 pin
- J8 10 pin
- J6 3 pin
- J7 8 pin
- J9 6 pin

Now install J5, the 10 pin dual row header

- J5

Locate the push-on jumpers and slide them over pins 1 & 2 or 2 & 3 of the jumper headers depending on your COS polarity requirements. Don't worry if you don't know which you need right now, as you can easily change them later.

- JP1, JP2, JP3, JP4, JP5, JP6

Install push-on jumpers over pins 2 & 3 of JP10, JP11 and JP12. This completes the audio path for the receiver amplifiers when the audio delay board is not installed:

- JP10, JP11, JP12

Install a push-on jumper on each of the 3 de-emphasis jumpers. You can skip this step if you plan on using flat audio on your repeater.

- JP7, JP8, JP9

Install a push-on jumper on JP13. This enables the LED's (you can remove it later if you wish to reduce current draw)

- JP13

# Check Your Work

Double check your work.

- All solder connections are bright and shiny.
- No solder bridges between IC socket pins.
- All components installed in their correct positions.
- Diodes, transistors, voltage regulators and electrolytic capacitors installed with their proper polarity.
- The pc board modifications are done correctly.

Congratulations! At this point your RC210 is completely assembled except for the integrated circuits. These will be installed after you run some voltage checks.

## Checking Voltages

For these tests, you will need to connect power to the RC210. It is suggested that you use a power supply with current limiting "just in case".

Locate the green, 4 pin power plug and connect it as follows:

- Pin 1            +11.5 to +15 Vdc
- Pins 3 & 4      Ground (both of these pins MUST be connected to the power supply's negative leads)

<u>Meter Plus Lead</u>	<u>Meter Minus Lead</u>	<u>Result</u>
<input type="checkbox"/> IC2, pin 16	Ground	+5 ± 5%
<input type="checkbox"/> U6, pin 24	Ground	Vcc ± 10% *
<input type="checkbox"/> U5, pin 4	U5, pin 11	Vcc ± 10% *
<input type="checkbox"/> U5, pin 12	U5, pin 11	1/2 Vcc ± 10%
<input type="checkbox"/> U7, pin 27	U7, pin 12	3.3v ± 5%

\* Vcc refers to the voltage supplied to the RC210.

If you do not obtain the results above, carefully check the PC board for cold solder joints, bridges or unsoldered connections.

If all is well, remove power. You're now ready to install the socketed integrated circuits.

- U1, U2, U3      MT(CM) 8870
- IC2                MAX232
- IC3, IC5         74HC595
- IC4, IC6         ULN2003A
- U4, U5            TL064
- U6                 MT8806
- U7                 ISD4003-M4

Your RC210 is now ready for installation and programming. Please consult the Operations Manual.

# If You Need Assistance

We offer several ways you can obtain assistance with your RC210:

Our email list (it's a good idea for all RC210 owners):

Send an email to: <mailto:rc210-subscribe@yahoogroups.com>

Or you may contact us directly at:

Arcom Communications  
24035 NE Butteville Rd.  
Aurora, Oregon 97002  
(503) 678-6182  
email: [arcom@arcomcontrollers.com](mailto:arcom@arcomcontrollers.com)

